



# Overviewtable

## Ultrasonic Sensors of the Series P42

Type / PDF Datasheet	Sensing Distance mm	Output	Interface	Connection	Adjustment Setpoint	Housing
<b>Sensorheads:</b>						
<a href="#">P42-400-M30-ST-C723</a>	400 - 4000	Signal measurement extern	-	C723	-	M30, Stainless Steel
<a href="#">P42-250-M30-ST-C723</a>	250 - 2500	"	-	"	-	"
<a href="#">P42-150-M30-ST-C723</a>	150 - 1500	"	-	"	-	"
<a href="#">P42-90-M30-ST-C723</a>	100 - 900	"	-	"	-	"
<b>Sensors with Integrated Measurement Electronics:</b>		<b>All Types: 2 x PNP, NO/NC</b>				
<a href="#">P42-350-M30-PBT-UI2P-RS232-C723</a>	350 - 3500	0 .. 10V, 4 .. 20mA	RS232	C723	Programmable	M30, PBT
<a href="#">P42-350-M30-PBT-U2P-RS485-C723</a>	"	0 .. 10V	RS485	"	"	"
<a href="#">P42-350-M30-PBT-I2P-RS485-C723</a>	"	4 .. 20mA	"	"	"	"
<a href="#">P42-300-M30-ST-U2P-</a>	300 - 3000	0 .. 10V	RS232	"	"	M30, Stainless



Type / PDF Datasheet	Sensing Distance mm	Output	Interface	Connection	Adjustment Setpoint	Housing
<b>Sensorheads:</b>						
<a href="#">RS232-C723</a>						Steel
<a href="#">P42-300-M30-ST-U2P- RS485-C723</a>	"	"	RS485	"	"	"
<a href="#">P42-300-M30-ST-I2P- RS232-C723</a>	"	4 .. 20mA	RS232	"	"	"
<a href="#">P42-300-M30-ST-I2P- R485-C724</a>	"	"	RS485	"	"	"
<a href="#">P42-200-M30-PBT- UI2P-RS232-C723</a>	250 - 2000	0 .. 10V, 4 .. 20mA	RS232	"	"	M30, PBT
<a href="#">P42-200-M30-ST-U2P- R232-C723</a>	"	0 .. 10V	"	"	"	M30, Stainless Steel
<a href="#">P42-200-M30-ST-I2P- R232-C723</a>	"	4 .. 20mA	"	"	"	"
<a href="#">P42-150-M30-PBT- U2P-RS232-C723</a>	150 - 1500	0 .. 10V	"	"	"	M30, PBT
<a href="#">P42-150-M30-PBT- U2P-RS485-C723</a>	"	"	RS485	"	"	"
<a href="#">P42-150-M30-PBT- I2P-RS232-C723</a>	"	4 .. 20mA	RS232	"	"	"



Type / PDF Datasheet	Sensing Distance mm	Output	Interface	Connection	Adjustment Setpoint	Housing
<b>Sensorheads:</b>						
<a href="#">P42-150-M30-PBT-I2P-RS485-C723</a>	"	"	RS485	"	"	"
<a href="#">P42-150-M30-ST-U2P-R232-C723</a>	"	0 .. 10V	RS232	"	"	M30, Stainless Steel
<a href="#">P42-150-M30-ST-U2P-R485-C723</a>	"	"	RS485	"	"	"
<a href="#">P42-150-M30-ST-I2P-R232-C723</a>	"	4 .. 20mA	RS232	"	"	"
<a href="#">P42-150-M30-ST-I2P-R485-C723</a>	"	"	RS485	"	"	"
<a href="#">P42-60-M30-ST-U2P-R232-C723</a>	100 - 600	0 .. 10V	RS232	"	"	"
<a href="#">P42-60-M30-ST-I2P-R232-C723</a>	"	4 .. 20mA	"	"	"	"
<b>Extern Measurement Electronics for Sensorheads:</b>						
<a href="#">P42-400-BOX-UI2P-RS232</a>	400 - 4000	0 .. 10V, 4 .. 20mA	RS232	-	-	-
<a href="#">P42-250-BOX-UI2P-</a>	250 - 2500	"	"	-	-	-



Type / PDF Datasheet	Sensing Distance mm	Output	Interface	Connection	Adjustment Setpoint	Housing
----------------------	------------------------	--------	-----------	------------	------------------------	---------

**Sensorheads:**

[RS232](#)

<u><a href="#">P42-150-BOX-UI2P-RS232</a></u>	150 - 1500	"	"	-	-	-
---	------------	---	---	---	---	---

<u><a href="#">P42-90-BOX-UI2P-RS232</a></u>	100 - 900	"	"	-	-	-
--	-----------	---	---	---	---	---

**Ultrasonic Sensor  
SET:**

<u><a href="#">P42-400-Set/M30-UI2P-RS232</a></u>	400 - 4000	0 .. 10V, 4 .. 20mA	RS232	C723	-	M30, Stainless Steel
---	------------	------------------------	-------	------	---	-------------------------

<u><a href="#">P42-250-Set/M30-UI2P-RS232</a></u>	250 - 2500	"	"	"	-	"
---	------------	---	---	---	---	---

<u><a href="#">P42-150-Set/M30-UI2P-RS232</a></u>	150 - 1500	"	"	"	-	"
---	------------	---	---	---	---	---

<u><a href="#">P42-90-Set/M30-UI2P-RS232</a></u>	100 - 900	"	"	"	-	"
--	-----------	---	---	---	---	---